


Canon PGI35 – CLI36

Once you've replaced your cartridges with a set of refilled cartridges, the ink level can't be read by the printer. Error messages will be displayed.

- Click OK and...
- Click Yes twice.
- Press the “Resume” button for 5 seconds.



Cartridge World[®]

Why pay more to print?

 REFILL - NOT LANDFILL[®]