

INSTRUCTIONS FOR CARTRIDGE WORLD BRANDED TRANSFER PAPER (DARK FABRIC)

Suitable for transferring black & white or colour images on to black or dark cotton using an iron.
Printing

1. Store dark transfer paper in a cool dry place in it's original packaging.
2. Only print onto the coated side of the transfer paper.
3. Select normal and not mirror mode on your printer. Use single sheet feeding only.
4. Printer settings: Normal paper mode using best printer setting.
5. Before transferring, leave the printed image to dry for approx. 5 minutes.
6. Cut out the image without leaving a margin around the edge, peel off the transfer backing.

Tip: First print the image on standard paper to check that the colour and size are correct

Transferring:

1. Prepare a stable, heat resistant surface suitable for ironing on.
2. Preheat the iron to the highest setting; the recommended ironing temperature is 200 degrees C.
3. Do not use a travel iron.
4. Briefly iron the fabric to ensure that it is completely smooth, and then place the transfer paper onto it face upwards.
5. In order to achieve a matt finish, cover the transfer with the greaseproof paper.
6. In order to achieve a glossy finish, cover the transfer with the silicone paper (red checked).
7. Do not use the steam function. Iron the transfer, gradually applying less pressure & making sure that the heat are evenly transferred over the entire area. Don't forget the corners & edges.
8. In order to gauge the correct ironing time allow 4 minutes for 1 A4 size image or 1 minute for a ¼ of an A4.
9. Allow the transfer to cool for a minimum of 1 minute then peel off the greaseproof or silicone paper in a smooth, even movement.
10. The same greaseproof or silicone sheet can be used more times.

Fixing:

1. The fixing process gives the transfer a fabric-like texture & improves the washing.
2. Allow the transfer to cool & re-iron with a greaseproof or silicone paper for 5-10 seconds.
3. After cooling for a minimum of 1 minute remove the greaseproof or silicone paper.

Washing:

1. Wash the garment / fabric before wearing / using.
2. Wait 24 hours before washing for the first time.
3. Fabrics bearing our transfers are machine washable up to 40 degrees C. Always wash garments inside out.



Cartridge World®

REFILL - NOT LANDFILL®

4. Do not use aggressive washing detergents or bleach of any kind.
5. Do not tumble dry.
6. When the textile is dry repeat the fixing process.
7. Avoid ironing directly over the transferred image.

For a glossy finish, allow the transfer to cool, then peel off the release paper in a smooth, even movement, starting from one corner.

3. Fixing

The fixing process removes any surplus ink from the transfer and gives the transfer a fabric like texture.

Matt finish: Allow the transfer to cool, then cover with a sheet of standard, white copy paper and press once again with the iron for 5-10 seconds. Immediately remove the paper while it is still hot.

Glossy finish: As above, except use greaseproof paper instead of copy paper and only remove when cold.

Mousepad: The fixing, for a matt and glossy finish, is only possible with greaseproof paper.



Cartridge World[®]

 REFILL - NOT LANDFILL[®]